Cleaning and Maintenance Manual

Traditional GRP (Glass Reinforced Plastic) Canopies

Regular cleaning and maintenance is essential to maintain its gloss and usability for a long time. A certain amount of light routine maintenance involving cleaning and washing is required.

This should be carried out every 4-6 months but can depend upon the canopy location and environment.

Maintaining and cleaning GRP canopies

Outdoors, the canopy can be exposed to a more aggressive environment if exposed to;

- a maritime atmosphere
- an industrial atmosphere
- · spatter from road salts
- air pollution and car fumes

All of these environments can cause brown spots to appear. A good rule of thumb is to clean the canopy surfaces just as often as the buildings windows, depending on the degree of contamination from the surroundings.

A damp cloth with warm soapy water or a chamois cloth is usually sufficient for wiping away light dirt, finger marks and any air-borne residue that can settle on the canopy surface. Then wipe down with a dry, soft cloth.

Alternatively we generally advise to hose down the canopy periodically with trepid water. For heavily soiled canopies (if left un-maintained for a long period of time) then hose down the canopy first to loosen particles. Use a pressure washer to remove fine residue and wipe down with a soft microfibre cloth.

Do not use any type of abrasive cleaner, scouring pads, mesh balls of metal wire, steel wool or metal brushes to clean any part of the canopy.

Spray cleaners are available on the market which make cleaning easier and leave a thin film for polished effect. Such cleaners remove finger-marks and reduce the tendency for new marks to keep forming. Buff with a soft dry cloth or rag.